

AGES 4+



Snuggimals™



Pet type and colors may vary.


CARE GUIDE

x1 BATTERY INCLUDED

Replace with 1 x 1.5V "AA" or LR6 size alkaline battery. Phillips/cross head screwdriver (not included) needed to replace battery.

Getting to Know Your Pet

Back sensor



Battery door on tummy

A sensor is a part of the toy that responds to your touch!


How to Play

Press your SNUGGIMALS pet on its back and it will wiggle around to show it's ready to play!

NOTE: When you're finished playing with your pet, store it on its tummy and be sure nothing is stacked on top or pressing the back sensor. This will help conserve battery life by preventing accidental activations.


Grooming Your Pet

Just like a real animal, your SNUGGIMALS pet likes to stay clean. But make sure it doesn't get wet! Gently brush its fur with a cloth or soft brush to loosen any dirt. You can use a slightly damp cloth to remove stains, but don't use any cleaners on your SNUGGIMALS pet.



To Replace Battery

1. Locate battery compartment on pet's tummy.
2. Loosen screw on battery door.
3. Remove and discard old battery.
4. Replace with fresh 1 x 1.5V "AA" or LR6 size alkaline battery.
5. Replace door and tighten screw.



NOTE TO UK CONSUMERS: This product and its battery must be disposed of separately at your local waste recycling centre. Do not dispose of in your household waste bin.

IMPORTANT: BATTERY INFORMATION



CAUTION:

1. Always follow the instructions carefully. Use only battery specified and be sure to insert it correctly by matching the + and - polarity markings.
2. Remove exhausted or dead battery from the product.
3. Remove battery if product is not to be played with for a long time.
4. Do not short-circuit the supply terminals.
5. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting battery) if necessary.
6. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**



Product and colors may vary.
© 2010 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.
Patent pending.

FurRealFriends.com

Questions? Call 1-800-844-3733